

IBB-33 - Iron Board Base 33"



The IBB-33 has three $\frac{3}{8}$ " bolt holes that need to be pre-drilled in your rigid board before installation. Each hole is $1\frac{3}{4}$ " from the bottom of the board. The center hole is $16\frac{3}{4}$ " from the side, and the side holes are 4" from each side. The Board Base covers the bottom $3\frac{1}{8}$ " of the board.

SETUP:

1. Pre-drill holes in your rigid board as described above and shown on the template. (Rigid board can be up to 1" thick)
2. Put the pre-drilled board in place between the two sides of the Iron Board Base, and push the base together.
3. Thread the bolts through the holes, and screw on all the wingnuts.